

Content

| | |
|--|----|
| 1 CANopen | 2 |
| 1.1 EDS Files | 2 |
| 1.2 Support | 2 |
| 1.3 Features | 2 |
| 1.3.1 Basic information | 2 |
| 1.3.2 Basics based on CiA 301, V4.2.0 | 2 |
| 1.3.3 Basics based on CiA DSP-406, V3.2 | 3 |
| 1.3.4 Basics SDO communication | 3 |
| 1.3.5 Basics PDO communication based on CiA 301, V4.2.0 | 3 |
| 1.4 Object Library | 4 |
| 1.4.1 Communication Profile Area based on DS 301 V4.2.0 | 4 |
| 1.4.2 Device Profile Area | 6 |
| 1.4.3 Manufacturer specific Area | 8 |
| 1.5 Explanations to Object Library | 9 |
| 1.5.1 Object 0x6000 Operating Parameter | 9 |
| 1.5.2 Object 0x6001 Measuring Step per Revolution | 9 |
| 1.5.3 Object 0x6002 Total Measuring Range in measuring units | 9 |
| 1.5.4 Object 0x6300 Encoder Cams | 9 |
| 1.5.5 Cam state registers | 9 |
| 1.5.6 Object 0x6400 Work Area | 9 |
| 1.5.6.1 Work Area State | 10 |
| 1.6 LSS / Layer Setting Service | 10 |
| 1.6.1 Configuration of Node-ID | 11 |
| 1.6.2 Configuration of Bit Rate | 11 |
| 1.6.3 Store Configuration Data | 11 |
| 1.7 SDO Services | 11 |
| 1.7.1 SDO Download | 12 |
| 1.7.2 SDO Upload | 12 |
| 1.7.3 SDO Abort | 13 |
| 1.8 Process Data PDO | 13 |
| 1.8.1 PDO Default Setting | 13 |
| 1.8.2 PDO Parameter Setting | 13 |
| 1.9 Error Handling | 14 |
| 1.9.1 Emergency Messages | 15 |
| 1.10 Error Objects | 15 |
| 1.10.1 Manufacturer-specific Status | 15 |
| 1.10.2 Alarms | 16 |
| 1.10.3 Warnings | 16 |
| 1.11 Non-Volatile Storage and Data Restoration | 16 |
| 1.12 Abbreviations | 18 |
| 1.13 Document Changes | 18 |

1 CANopen

This document reflects the Novotechnik sensor protocol implementation of the standard CANopen protocol.
A basic knowledge of the CAN Bus is required for a proper understanding of this document.
Most of the definitions made are according to the following CiA Standard specifications.
For making use of all the features that these specifications offer, a knowledge about them is absolutely necessary.
The sensor supports the CANopen Communication profile DS-301, V4.2.0, Encoder profile DSP-406, V3.2 and
Layer Setting Services (LSS) DSP-305, V1.1.2.

1.1 EDS Files

For integration in a common CANopen projecting tool, electronic data sheet (*.eds) files are provided.
These files can be downloaded from the Novotechnik Web Site, see Downloads/Operating manuals
where also this document can be found.

⇒ **Electric data sheet see file *Product series_CANopen 1channel.eds* or *Product series_CANopen 2channel.eds***

1.2 Support

If you have any questions, please contact our product support at support@novotechnik.de.
Electronic data sheets or user manuals for previous software versions are available on request.

1.3 Features

1.3.1 Basic information

Vendor ID: 386 = 0x0182 (Novotechnik)
Product code: 03040 = 0x0BE0 => product series RFC-4800
03059 = 0x0BF3 => product series RSA-3200
03005 = 0x0BBB => product series RFE-3200
03021 = 0x0BCD => product series RSX-7900
03041 = 0x0BE1 => product series RFX-6900
Rev.-No.: f.e 65539 = 0x10003
Serial No.: see product label, "B/N XXXXXX/YYY" (6+3 characters)

1.3.2 Basics based on CiA 301, V4.2.0

| | | |
|--------------------|--|-----------------|
| CAN Identifier | Standard 11 bits according to pre-defined connection set: | |
| | <u>Services</u> | <u>COB-ID</u> |
| | NMT | 0x00 |
| | SYNC | 0x080 |
| | EMCY | 0x080 + Node-ID |
| | PDO1 (Tx) | 0x180 + Node-ID |
| | PDO2 (Tx) | 0x280 + Node-ID |
| | SDO (Rx) | 0x600 + Node-ID |
| | SDO (Tx) | 0x580 + Node-ID |
| CAN Bit rates | Bit rate is defined in the ordering code: | |
| | 6_7: 50 kBaud 6_5: 125 kBaud 6_4: 250 kBaud 6_3: 500 kBaud 6_2: 800 kBaud 6_1: 1000 kBaud setting per LSS (see chapter 1.6 LSS / Layer Setting Service) or object 0x2001 (see chapter 1.7 SDO Services) | |
| Node-ID | standard models 127 = 0x7F (can deviate for customized models) setting per LSS (see chapter 1.6 LSS / Layer Setting Service) or object 0x2000 (see chapter 1.7 SDO Services) | |
| SYNC | Consumer | |
| Time Stamp | no | |
| Emergency Messages | Producer | |
| Node Guarding | yes | |
| Heartbeat | Producer | |

| | |
|----------------------|-------|
| Non-volatile storage | yes |
| Program Download | no |
| NMT Service | Slave |

1.3.3 Basics based on CiA DSP-406, V3.2

| | |
|---|--|
| Encoder class | <input type="checkbox"/> C1 <input checked="" type="checkbox"/> C2 |
| Encoder type | Absolute Rotary Multi Sensor Encoder Interface |
| Max. bit bandwidth of position value | 14 bits |
| Resolution speed | $360^\circ/2^{14} \sim 0.022^\circ/\text{ms}$ |
| Encoder Cams Channels to be detected Cams per channel Polarity Hysteresis | Pos.ch1, Pos.ch2 4 invertable yes |
| Work Area Supervision channels | Pos.ch1, Pos.ch2 |

1.3.4 Basics SDO communication

| | |
|--------------------|----------|
| SDO communication | 1 Server |
| expedited transfer | yes |
| segmented transfer | no |
| Block transfer | no |

1.3.5 Basics PDO communication based on CiA 301, V4.2.0

| | |
|-----------------------------|---|
| PDO communication principle | Producer |
| TPDO's | TPDO1: Event-driven transmission <ul style="list-style-type: none"> - Synchronous to measurement cycle (1 ms with delay 300 μs) - Event Timer Synchronous (SYNC Object) TPDO2: Synchronous (SYNC Object) |
| PDO Mapping | dynamic |
| max. PDO Mappings per PDO | 5 |

1.4 Object Library

1.4.1 Communication Profile Area based on DS 301 V4.2.0

| Object description | | | Entry description | | | |
|--------------------|-------------------------------|----------------|-------------------|----------------|---------------------------|---|
| Index/ subindex | Name | Data Type | Access | PDO Mapping | Default value | Comment |
| 1000 | device type | unsigned32 | const | no | 0x00010196 | Device profile 406 multi-sensor encoder interface |
| 1001 | error register | unsigned8 | ro | no | 0x00 | See chapter 1.9 Error Handling |
| 1002 | manufacturer status register | unsigned32 | ro | no | 0x00000000 | Additional manufacturer spec. status register |
| 1005 | COB-ID SYNC | unsigned32 | rw | no | 0x00000080 | COB-ID SYNC message (CAN-identifier) |
| 1008 | manufacturer device name | visible_string | const | no | e.g. RFC-4801-214-614-511 | Device name, see datasheet/ordering code |
| 1009 | manufacturer hardware version | visible_string | const | no | e.g. V 1.00 | Hardware version release |
| 100A | manufacturer software version | visible_string | const | no | e.g. V 1.03 | Software version release |
| 100C | guard time | unsigned16 | rw | no | 0x00000000 disabled | Time base (in ms), which gives combined with 100D the time in which the response of the node guard is expected |
| 100D | life time factor | unsigned8 | rw | no | 0x00000000 disabled | The life time factor multiplied with the guard time gives the life time for the device. |
| 1010 | store parameter field | unsigned32 | | | | This entry supports saving of parameters in non volatile memory. With a read access the device provides information about its saving capabilities. For saving the signature "save" (0x65766173) must be written. |
| 1010/1 | store parameter field | unsigned32 | rw | no | 0x00000000 | Save all parameters |
| 1010/2 | | unsigned32 | rw | no | 0x00000000 | Save communication parameters |
| 1010/3 | | unsigned32 | rw | no | 0x00000000 | Save application parameters |
| 1010/4 | | unsigned32 | rw | no | 0x00000000 | Save user data parameters Only RSX-7900/RFX-6900 series: Save manufacturer defined parameters |
| 1010/5 | | unsigned32 | rw | no | 0x00000000 | Not RSX-7900/RFX-6900 series: Save manufacturer defined parameters (Caution, see chapter 1.11.) |
| 1011 | restore default parameters | unsigned32 | | | | This entry supports restoring of default parameters. With a read access the device provides information about its capabilities to restore these values. For restoring the signature "load" (0x646166c) must be written. |
| 1011/1 | restore default parameters | unsigned32 | rw | no | 0x00000000 | Restore all default parameters |
| 1011/2 | | unsigned32 | rw | no | 0x00000000 | Restore communication default parameters |
| 1011/3 | | unsigned32 | rw | no | 0x00000000 | Restore application default parameters |
| 1011/4 | | unsigned32 | rw | no | 0x00000000 | Restore user data parameters Only RSX-7900/RFX-6900 series: Restore manufacturer defined parameters |
| 1014 | COB-ID EMCY | unsigned32 | ro | no | 0x00000080 + Node-ID | COB-ID used for emergency message (Emergency Server). |
| 1017 | producer heart-beat time | unsigned16 | rw | no | 0x0000 disabled | Heartbeat time periode in ms. Range 0...0xFFFF |
| 1018 | identify object | identity | | | | General information about the device. This information is also used as the LSS address when using "switch mode selective" command |
| 1018/1 | | unsigned32 | ro | no | 0x00000182 | Vendor ID |

| Object description | | | Entry description | | | |
|--------------------|-------------------------------|--------------|-------------------|----------------|--|--|
| Index/ subindex | Name | Data Type | Access | PDO Mapping | Default value | Comment |
| 1018/2 | Identify object | unsigned32 | ro | no | 0x0 (see 1.3.1 Basic information) | Product code |
| 1018/3 | | unsigned32 | ro | no | (see 1.3.1 Basic information) | Revision number |
| 1018/4 | | unsigned32 | ro | | (see 1.3.1 Basic information) | Serial number |
| 1800 | TPDO1 communication parameter | PDO_COMM_PAR | | | | It contains the communication parameters of the current PDO the device is able to transmit. |
| 1800/1 | | unsigned32 | rw | no | 0x40000180 + Node ID | COB-ID of the PDO |
| 1800/2 | | unsigned8 | rw | no | 0xFE =254 | Transmission modes: TPDO off: 0 Event-driven transmission - Synchronous to meas. cycle: 255 - Event Timer: 254 Synchronous: 1 ... 240 |
| 1800/3 | | unsigned16 | rw | no | 0x0000 | Inhibit Time in (multiples of) 100 µs |
| 1800/4 | | unsigned8 | rw | no | 0x00 | Compatibility entry |
| 1800/5 | | unsigned16 | rw | no | 0x0000 disabled | Event timer in ms Disabled: 0 Enabled: Range 1 ... 65535 |
| 1801 | TPDO2 communication parameter | PDO_COMM_PAR | | | | It contains the communication parameters of the current PDO the device is able to transmit. |
| 1801/1 | | unsigned32 | rw | no | 0x40000280 + Node ID | COB-ID of the PDO |
| 1801/2 | | unsigned8 | rw | no | 0x01 | Transmission mode: TPDO off: 0 Synchronous: 1 ... 240 |
| 1801/3 | | unsigned16 | rw | no | 0x0000 | Inhibit Time in (multiples of) 100µs |
| 1A00 | TPDO1 mapping parameter | PDO_MAPPING | | | | Contains the mapping for the PDOs the device is able to transmit |
| 1A00/0 | | unsigned8 | rw | no | 0x02 | Number of entries |
| 1A00/1 | | unsigned32 | rw | no | 0x60200120 | Mapping entry 1, default: Position value channel 1 |
| 1A00/2 | | unsigned32 | rw | no | 0x60300110 ¹⁾ 0x60200220 ²⁾ | Mapping entry 2, default: Speed value channel 1 ¹⁾ default: Position value channel 2 ²⁾ |
| 1A00/3 | | unsigned32 | rw | no | 0x00000000 | Mapping entry 3 |
| 1A00/4 | | unsigned32 | rw | no | 0x00000000 | Mapping entry 4 |
| 1A00/5 | | unsigned32 | rw | no | 0x00000000 | Mapping entry 5 |
| 1A01 | TPDO2 mapping parameter | PDO_MAPPING | | | | Contains the mapping for the PDOs the device is able to transmit |
| 1A01/0 | TPDO2 mapping parameter | unsigned8 | rw | no | 0x02 | Number of entries |
| 1A01/1 | | unsigned32 | rw | no | 0x60200120 | Mapping entry 1, default: Position value channel 1 |
| 1A01/2 | | unsigned32 | rw | no | 0x60300110 ¹⁾ 0x60200220 ²⁾ | Mapping entry 2, default: Speed value channel 1 ¹⁾ default: Position value channel 2 ²⁾ |
| 1A01/3 | | unsigned32 | rw | no | 0x00000000 | Mapping entry 3 |
| 1A01/4 | | unsigned32 | rw | no | 0x00000000 | Mapping entry 4 |
| 1A01/5 | | unsigned32 | rw | no | 0x00000000 | Mapping entry 5 |
| 1F80 | NMT startup | unsigned32 | rw | no | 0x00000000 | This object determines the startup behavior of a device in the network. Bit 3 set: sensor starts in operational mode |

¹⁾ for one-channel version

²⁾ for two-channel version

1.4.2 Device Profile Area

* for one-channel version: default value 0x01

** for one-channel version: not available

| Object description | | | Entry description | | | |
|--------------------|--|------------|-------------------|----------------|---------------|---|
| Index/ subindex | Name | Data Type | Access | PDO Mapping | Default value | Comment |
| 6000 | operating parameter | unsigned16 | rw | no | 0x0000 | This object contains the functions for code sequence (counting direction), commissioning diagnostic control and scaling function control |
| 6001 | measuring units per revolution | unsigned32 | rw | no | 0x00004000 | Object sets the number of distinguishable steps per revolution (singleturn resolution) |
| 6002 | total measuring range in measuring units | unsigned32 | rw | no | 0x00004000 | Object sets the number of distinguishable steps over the total measuring range (total resolution) |
| 6010 | preset value | | | | | This object supports adaption of the encoder zero point to the mechanical zero point of the system |
| 6010/0 | | unsigned8 | ro | no | 0x02* | Number of available channels |
| 6010/1 | | integer32 | rw | no | 0x00000000 | Preset value channel 1 |
| 6010/2 | | integer32 | rw | no | 0x00000000** | Preset value channel 2 |
| 6020 | position value | | | | | This object defines the output position value |
| 6020/0 | | unsigned8 | ro | no | 0x02* | Number of available channels |
| 6020/1 | | integer32 | ro | yes | 0x00000000 | Position value channel 1 |
| 6020/2 | | integer32 | ro | yes | 0x00000000** | Position value channel 2 |
| 6030 | speed value | | | | | This object defines the output speed value |
| 6030/0 | | unsigned8 | ro | no | 0x02* | Number of available channels |
| 6030/1 | | integer16 | ro | yes | 0x0000 | Speed value channel 1 |
| 6030/2 | | integer16 | ro | yes | 0x0000** | Speed value channel 2 |
| 6300 | CAM state register | | | | | defines the status bit of the cam in a cam channel. The bit value 0 means "cam inactive". The bit value 1 means "cam active". If the polarity bit of a cam is set the actual cam state will be inverted. |
| 6300/0 | | unsigned8 | ro | no | 0x02* | Number of available channels |
| 6300/1 | | unsigned8 | ro | yes | 0x00 | CAM state channel 1 |
| 6300/2 | | unsigned8 | ro | yes | 0x00** | CAM state channel 2 |
| 6301 | CAM enable | | | | | This object contains the calculation state for 4 cams for one position channel. If the enable bit is set to 1, the cam state will be calculated by the device. In the other case the cam state of the related cam will be set permanently to 0. |
| 6301/0 | CAM enable | unsigned8 | ro | no | 0x02* | Number of available channels |
| 6301/1 | | unsigned8 | rw | no | 0x00 | CAM enable channel 1 |
| 6301/2 | | unsigned8 | rw | no | 0x00** | CAM enable channel 2 |
| 6302 | CAM polarity register | | | | | This object contains the actual polarity settings for 4 cams for one position channel. If the polarity bit is set to 1, the cam state of an active cam will signal by setting the related cam state bit to zero. In the other case the cam state of the related cam will not be inverted. |
| 6302/0 | | unsigned8 | ro | no | 0x02* | Number of available channels |
| 6302/1 | | unsigned8 | rw | no | 0x00 | CAM polarity channel 1 |
| 6302/2 | | unsigned8 | rw | no | 0x00** | CAM polarity channel 2 |
| 6310 | CAM 1 low limit | | | | | determines the lower limit of position for cam 1 |
| 6310/0 | | unsigned8 | ro | no | 0x02* | Number of available channels |
| 6310/1 | | integer32 | rw | no | 0x00000000 | CAM 1 low limit channel 1 |
| 6310/2 | | Integer32 | rw | no | 0x00000000** | CAM 1 low limit channel 2 |

| Object description | | | Entry description | | | |
|--------------------|---------------------|------------|-------------------|----------------|---------------|---|
| Index/ subindex | Name | Data Type | Access | PDO Mapping | Default value | Comment |
| 6311 | CAM 2 low limit | | | | | determines the lower limit of position for cam 2 |
| 6311/0 | | unsigned8 | ro | no | 0x02* | Number of available channels |
| 6311/1 | | integer32 | rw | no | 0x00000000 | CAM 2 low limit channel 1 |
| 6311/2 | | Integer32 | rw | no | 0x00000000** | CAM 2 low limit channel 2 |
| 6312 | CAM 3 low limit | | | | | determines the lower limit of position for cam 3 |
| 6312/0 | | unsigned8 | ro | no | 0x02* | Number of available channels |
| 6312/1 | | integer32 | rw | no | 0x00000000 | CAM 3 low limit channel 1 |
| 6312/2 | | Integer32 | rw | no | 0x00000000** | CAM 3 low limit channel 2 |
| 6313 | CAM 4 low limit | | | | | determines the lower limit of position for cam 4 |
| 6313/0 | | unsigned8 | ro | no | 0x02* | Number of available channels |
| 6313/1 | | integer32 | rw | no | 0x00000000 | CAM 4 low limit channel 1 |
| 6313/2 | | Integer32 | rw | no | 0x00000000** | CAM 4 low limit channel 2 |
| 6320 | CAM 1 high limit | | | | | determines the higher limit of position for cam 1 |
| 6320/0 | | unsigned8 | ro | no | 0x2* | Number of available channels |
| 6320/1 | | integer32 | rw | no | 0x00003FFF | CAM 1 high limit channel 1 |
| 6320/2 | | Integer32 | rw | no | 0x00003FFF** | CAM 1 high limit channel 2 |
| 6321 | CAM 2 high limit | | | | | determines the higher limit of position for cam 2 |
| 6321/0 | | unsigned8 | ro | no | 0x02* | Number of available channels |
| 6321/1 | | integer32 | rw | no | 0x00003FFF | CAM 2 high limit channel 1 |
| 6321/2 | | Integer32 | rw | no | 0x00003FFF** | CAM 2 high limit channel 2 |
| 6322 | CAM 3 high limit | | | | | determines the higher limit of position for cam 3 |
| 6322/0 | | unsigned8 | ro | no | 0x02* | Number of available channels |
| 6322/1 | | integer32 | rw | no | 0x00003FFF | CAM 3 high limit channel 1 |
| 6322/2 | | Integer32 | rw | no | 0x00003FFF** | CAM 3 high limit channel 2 |
| 6323 | CAM 4 high limit | | | | | determines the higher limit of position for cam 4 |
| 6323/0 | | unsigned8 | ro | no | 0x02* | Number of available channels |
| 6323/1 | | integer32 | rw | no | 0x00003FFF | CAM 4 high limit channel 1 |
| 6323/2 | | Integer32 | rw | no | 0x00003FFF** | CAM 4 high limit channel 2 |
| 6330 | CAM 1 hysteresis | | | | | This object contains the delay setting of switch points for cam 1 |
| 6330/0 | | unsigned8 | ro | no | 0x02* | Number of available channels |
| 6330/1 | | unsigned16 | rw | no | 0x0000 | CAM 1 hysteresis channel 1 |
| 6330/2 | | unsigned16 | rw | no | 0x0000** | CAM 1 hysteresis channel 2 |
| 6331 | CAM 2 hysteresis | | | | | This object contains the delay setting of switch points for cam 2 |
| 6331/0 | | unsigned8 | ro | no | 0x02* | Number of available channels |
| 6331/1 | | unsigned16 | rw | no | 0x0000 | CAM 2 hysteresis channel 1 |
| 6331/2 | | unsigned16 | rw | no | 0x0000** | CAM 2 hysteresis channel 2 |
| 6332 | CAM 3 hysteresis | | | | | This object contains the delay setting of switch points for cam 3 |
| 6332/0 | | unsigned8 | ro | no | 0x02* | Number of available channels |
| 6332/1 | | unsigned16 | rw | no | 0x0000 | CAM 3 hysteresis channel 1 |
| 6332/2 | | unsigned16 | rw | no | 0x0000** | CAM 3 hysteresis channel 2 |
| 6333 | CAM 4 hysteresis | | | | | This object contains the delay setting of switch points for cam 4 |
| 6333/0 | | unsigned8 | ro | no | 0x02* | Number of available channels |
| 6333/1 | | unsigned16 | rw | no | 0x0000 | CAM 4 hysteresis channel 1 |
| 6333/2 | | unsigned16 | rw | no | 0x0000** | CAM 4 hysteresis channel 2 |
| 6400 | area state register | | | | | This object contains the actual area status of the encoder position. <u>Bit meaning</u> 0 out of range 1 range overflow 2 range underflow |
| 6400/0 | | unsigned8 | ro | no | 0x02* | Number of available work areas |
| 6400/1 | | unsigned8 | ro | yes | 0x00000000 | Work area state channel 1 |
| 6400/2 | | unsigned8 | ro | yes | 0x00000000** | Work area state channel 2 |

| Object description | | | Entry description | | | |
|--------------------|---|------------|-------------------|----------------|--|---|
| Index/ subindex | Name | Data Type | Access | PDO Mapping | Default value | Comment |
| 6401 | work area low limit | | | | | This object contains the lower limit of the work area |
| 6401/0 | | unsigned8 | ro | no | 0x02* | Number of available work areas |
| 6401/1 | | integer32 | rw | no | 0x00000000 | Low limit work area 1 |
| 6401/2 | | integer32 | rw | no | 0x00000000** | Low limit work area 2 |
| 6402 | work area high limit | | | | | This object contains the higher limit of the work area |
| 6402/0 | | unsigned8 | ro | no | 0x02* | Number of available channels |
| 6402/1 | | integer32 | rw | no | 0x00003FFF | High limit work area 1 |
| 6402/2 | | integer32 | rw | no | 0x00003FFF** | High limit work area 2 |
| 6500 | operating status | unsigned16 | ro | no | 0x0000 | This gives information on encoder internal programmed parameters. |
| 6501 | measuring units per resolution | unsigned32 | ro | no | 0x00004000 | This object gives the number of steps per revolution that are output for the absolute singleturn position value. |
| 6502 | number of distinguishable revolutions | unsigned16 | ro | no | Singleturn: 0x0001 Multiturn: e.g. 0x0010 | This object contains the number of distinguishable revolutions that the multiturn-encoder can output. e.g. Multiturn with 16 revolutions |
| 6503 | alarms | unsigned16 | ro | yes | 0x0000 | This object shows, which alarm is active |
| 6504 | supported alarms | unsigned16 | ro | no | 0x1001 | This object informs on alarms sup- ported by the encoder |
| 6505 | warnings | unsigned16 | ro | yes | 0x0000 | This object reports warnings. |
| 6506 | supported warnings | unsigned16 | ro | no | 0x1000 | This object informs on warnings supported by the encoder |
| 6507 | profile and software version | unsigned32 | ro | no | e.g. 0x01020302 | This object reports the versions: byte 3-2: software version byte 1-0: profile version |

or one-channel version: default value 0x01

** for one-channel version: not available

1.4.3 Manufacturer specific Area

| Object description | | | Entry description | | | |
|--------------------|--------------|------------|-------------------|----------------|-----------------------------------|--|
| Index/ subindex | Name | Data Type | Access | PDO Mapping | Default value | Comment |
| 2000 | node-ID | unsigned8 | rw | no | 0x7F | Node-ID of the sensor Range 1...127 |
| 2001 | CAN bit rate | unsigned16 | rw | no | as defined by ordering code | CAN bit rate of the sensor in kbit/s Only RSX-7900/RFX-6900 series: CAUTION: Once the "reset all" operation is performed (see chapter 1.10), even if the factory (delivered) bit rate was a different one, the bit rate will be reset to 250kBaud =0x00FA |
| 2003 | ordering | | | | | Manufacturer defined array, not writable for the user |
| 2004 | custom | | | | | Manufacturer defined array, not writable for the user |

1.5 Explanations to Object Library

1.5.1 Object 0x6000 Operating Parameter

This object contains the function for **the counting direction**.

The counting direction clockwise (cw) or counterclockwise (ccw) is defined whether the signal values are rising or falling when sensor shaft or position marker is rotated cw (view on the position marker or shaft).

Bit 0 = 0: counting direction cw

Bit 0 = 1: counting direction ccw

This object also includes the **switching on and off of the scaling function**, which is required to change the sensor resolution.

Bit 2 = 0: scaling off

Bit 2 = 1: scaling on (further scaling is done by objects 0x6001 or 0x6002)

This object also includes the **moving average function for position and speed calculation**:

Bit 14...12 = 0: moving average function off

Bit 14...12 = n: moving average over 2^n values ($n = 1...7$)

1.5.2 Object 0x6001 Measuring Step per Revolution

This object sets the number of distinguishable steps per revolution.

Writing is only possible if scaling (0x6000 / Bit 2) is on. Changes of this objects also changes object 0x6002.

The default value 0x4000 (14 bits) is the maximum step size per revolution. The resolution can only be reduced.

1.5.3 Object 0x6002 Total Measuring Range in measuring units

This object sets the number of distinguishable steps over the total measuring range. Writing is only possible if scaling (0x6000 / Bit 2) is on. Changes of this objects also changes object 0x6001.

The default value 0x4000 (14 bits) is the maximum total step size. The resolution can only be reduced.

1.5.4 Object 0x6300 Encoder Cams

Encoder cams are used to indicate if a position falls below or exceeds a defined value.

1.5.5 Cam state registers

Cam active: the current position value is between the higher and lower cam-limit

Cam inactive: the current position value is not between the higher and lower cam-limit.

The values for low limit (0x631x) and high limit (0x632x) regard the values for preset (0x6010) and measuring units per resolution (0x6001). The value of hysteresis (0x633x) is added in direction of motion.

Note: The cam high limit value can have a lower value than the cam low limit

A change in cam state causes an EMCY message.

The cam state objects (0x6300) are able to be mapped to the TPDOs.

1.5.6 Object 0x6400 Work Area

It is possible for encoders to define a so-called user defined working area.

The main purpose for a work area is to get a high-priority information (via EMCY message) when the transducer's position leaves its predefined working area.

The actual work area information with work area low limit and work area high limit may be stored in object 0x6401 and 0x6402. This way, the area state object (0x6400) may also be used as software limit switches.

1.5.6.1 Work Area State

| Condition | State register 0x6400 |
|---|------------------------|
| Position < Work Area Low Limit Position >= Work Area Low Limit | Bit 2 = 1 Bit 2 = 0 |
| Position > Work Area High Limit Position <= Work Area High Limit | Bit 1 = 1 Bit 1 = 0 |
| Position <= Preset Value or Position >= Sensor length otherwise | Bit 0 = 1 Bit 0 = 0 |

The values for low limit (0x6401) and high limit (0x6402) regard the values for preset (0x6010) and scaling (0x6501, 0x6502).

A change in work area state causes an EMCY message.
The work area state objects (0x6400) are able to be mapped to the TPDOs.

1.6 LSS / Layer Setting Service

To configure the encoder via the LSS (according CiA DS 305) the encoder is handled as a slave, the PLC must have a LSS master functionality.

A LSS-message is composed as follows:

| COB-ID | DLC | Command | Byte0 | Byte1 | Byte2 | Byte3 | Byte4 | Byte5 | Byte6 |
|--------|-----|---------|-------|-------|-------|-------|-------|-------|-------|
|--------|-----|---------|-------|-------|-------|-------|-------|-------|-------|

This applies to the COB-ID:

- LSS-Master ⇒ LSS-Slave: 2021 (0x7E5)
- LSS-Slave ⇒ LSS-Master: 2020 (0x7E4)

LSS can only be used when the encoder is in the stopped status or pre-operational status.
The NMT command for setting the encoder in stopped status is:

| COB-ID | DLC | Command | Byte0 | Byte1 | Byte2 | Byte3 | Byte4 | Byte5 | Byte6 |
|--------|-----|---------|-------|-------|-------|-------|-------|-------|-------|
| 0x7E5 | 8 | 0x04 | 0x00 | 0x00 | 0x00 | 0x00 | 0x00 | 0x00 | 0x00 |

To program via LSS the sensor has to be switched to LSS configuration state.
There are two possible ways to do so:

- **Switch Mode Selective:**
only the addressed CANopen device is switched to the LSS configuration state

LSS requires data content in the following objects:

Example:

| | | | |
|--------------|--------------------|------------|------------------|
| Vendor-ID | (see index 1018/1) | 0x0182 | LSS-Command 0x40 |
| Product code | (see index 1018/2) | 0x0BE0 | LSS-Command 0x41 |
| Rev.No. | (see index 1018/3) | 0x10003 | LSS-Command 0x42 |
| Serial-No. | (see index 1018/4) | 0x12345678 | LSS-Command 0x43 |

After receiving the identification objects, the encoder answers with LSS-Command **0x44**.

| COB-ID | DLC | Rx/ Tx | Command | Byte0 | Byte1 | Byte2 | Byte3 | Byte4 | Byte5 | Byte6 |
|--------|-----|-----------|---------|-------|-------|-------|-------|-------|-------|-------|
| 0x7E5 | 8 | Rx | 0x40 | 0x82 | 0x01 | 0x00 | 0x00 | 0x00 | 0x00 | 0x00 |
| 0x7E5 | 8 | Rx | 0x41 | 0xE0 | 0x0B | 0x00 | 0x00 | 0x00 | 0x00 | 0x00 |
| 0x7E5 | 8 | Rx | 0x42 | 0x03 | 0x00 | 0x01 | 0x00 | 0x00 | 0x00 | 0x00 |
| 0x7E5 | 8 | Rx | 0x43 | 0x78 | 0x56 | 0x34 | 0x12 | 0x00 | 0x00 | 0x00 |
| 0x7E4 | 8 | Tx | 0x44 | 0x00 | 0x00 | 0x00 | 0x00 | 0x00 | 0x00 | 0x00 |

- **Switch Mode Global:** all CANopen devices supporting LSS are switched to the LSS configuration state

| COB-ID | DLC | Rx/Tx | Command | Byte0 | Byte1 | Byte2 | Byte3 | Byte4 | Byte5 | Byte6 |
|--------|-----|-------|---------|-------|-------|-------|-------|-------|-------|-------|
| 0x7E5 | 8 | Rx | 0x04 | 0x01 | 0x00 | 0x00 | 0x00 | 0x00 | 0x00 | 0x00 |

When the CAN devices are in configuration state the Node-ID and/or the bit rate can be changed.

1.6.1 Configuration of Node-ID

The Node-ID can be programmed with the LSS-Command **0x11**

N ID: new Node-ID in the range of 1...127

Err Code: 0: protocol successfully completed / 1: Node-ID out of range

| COB-ID | DLC | Rx/Tx | Command | Byte0 | Byte1 | Byte2 | Byte3 | Byte4 | Byte5 | Byte6 |
|--------|-----|-------|---------|----------|-------|-------|-------|-------|-------|-------|
| 0x7E5 | 8 | Rx | 0x11 | N ID | 0x00 | 0x00 | 0x00 | 0x00 | 0x00 | 0x00 |
| 0x7E4 | 8 | Tx | 0x11 | Err Code | 0x00 | 0x00 | 0x00 | 0x00 | 0x00 | 0x00 |

Change of Node-ID will cause:

- Automatic alteration of COB-ID's for SDO1, EMCY and Heartbeat and TPDOs.
- Non-volatile Node-ID storage through „Store Configuration“ in the LSS mode configuration.

1.6.2 Configuration of Bit Rate

The Bit Rate can be programmed with LSS-Command **0x13**

Table Index: 0x06: 50 kBaud

0x04: 125 kBaud

0x03: 250 kBaud

0x02: 500 kBaud

0x01: 800 kBaud

0x00: 1000 kBaud

Err Code: 0: protocol successfully completed 1: Bit timing not supported

| COB-ID | DLC | Rx/Tx | Command | Byte0 | Byte1 | Byte2 | Byte3 | Byte4 | Byte5 | Byte6 |
|--------|-----|-------|---------|-------------|-------|-------|-------|-------|-------|-------|
| 0x7E5 | 8 | Rx | 0x13 | Table Index | 0x00 | 0x00 | 0x00 | 0x00 | 0x00 | 0x00 |
| 0x7E4 | 8 | Tx | 0x13 | Err Code | 0x00 | 0x00 | 0x00 | 0x00 | 0x00 | 0x00 |

Change of Bit rate will cause:

- The bit rate gets active
- Non-volatile CAN bit rate storage through „Store Configuration“ in the LSS mode configuration

1.6.3 Store Configuration Data

The LSS configuration data (Node-ID and Bit Rate) are stored to the non-volatile memory of the sensor using LSS-Command **0x17**

Err Code: 0: protocol successfully completed 2: storage media access error

| COB-ID | DLC | Rx/Tx | Command | Byte0 | Byte1 | Byte2 | Byte3 | Byte4 | Byte5 | Byte6 |
|--------|-----|-------|---------|----------|-------|-------|-------|-------|-------|-------|
| 0x7E5 | 8 | Rx | 0x17 | 0x00 | 0x00 | 0x00 | 0x00 | 0x00 | 0x00 | 0x00 |
| 0x7E4 | 8 | Tx | 0x17 | Err Code | 0x00 | 0x00 | 0x00 | 0x00 | 0x00 | 0x00 |

1.7 SDO Services

Service Data Objects SDO (according to CiA DS 301) manage the parameter data exchange, e.g. the non-cyclical execution of the preset function.

Parameters of device object library (object index/subindex see chapter 1.4 *Object Library*) can be read, written or stored by means of SDO.

1.7.1 SDO Download

The SDO download service is used to configure the parameters.

Command 0x2_: 0x22 write command, parameter to encoder
0x23 write command, 4 Byte parameter to encoder
0x27 write command, 3 Byte parameter to encoder
0x2B write command, 2 Byte parameter to encoder
0x2F write command, 1 Byte parameter to encoder
Command 0x60: confirmation: parameter received

| COB-ID | DLC | Rx/ Tx | Command | Byte0 | Byte1 | Byte2 | Byte3 | Byte4 | Byte5 | Byte6 |
|---------------|-----|-----------|---------|-------|-------|-----------|----------|-------|-------|----------|
| 0x600+Node-ID | 8 | Rx | 0x2_ | Index | | Sub-index | Data LSB | Data | Data | Data MSB |
| 0x580+Node-ID | 8 | Tx | 0x60 | Index | | Sub-index | 0x00 | 0x00 | 0x00 | 0x00 |

Example: object index 0x1010 subindex 01 "store all parameters"

| | | | | | | | | | | |
|---------------|---|----|------|------|------|------|------|------|------|------|
| 0x600+Node-ID | 8 | Rx | 0x23 | 0x10 | 0x10 | 0x01 | 0x73 | 0x61 | 0x76 | 0x65 |
| 0x580+Node-ID | 8 | Tx | 0x60 | 0x10 | 0x10 | 0x01 | 0x00 | 0x00 | 0x00 | 0x00 |

Example: object index 0x1011 subindex 01 "restore all parameters"

| | | | | | | | | | | |
|---------------|---|----|------|------|------|------|------|------|------|------|
| 0x600+Node-ID | 8 | Rx | 0x23 | 0x11 | 0x10 | 0x01 | 0x6C | 0x6F | 0x61 | 0x64 |
| 0x580+Node-ID | 8 | Tx | 0x60 | 0x11 | 0x10 | 0x01 | 0x00 | 0x00 | 0x00 | 0x00 |

Example: object index 0x2000 "set new node-ID" with 0x40

| | | | | | | | | | | |
|---------------|---|----|------|------|------|------|------|------|------|------|
| 0x600+Node-ID | 8 | Rx | 0x2F | 0x00 | 0x20 | 0x00 | 0x40 | 0x00 | 0x00 | 0x00 |
| 0x580+Node-ID | 8 | Tx | 0x60 | 0x00 | 0x20 | 0x00 | 0x00 | 0x00 | 0x00 | 0x00 |

NODE-ID

Using writing to object 0x2000, non-volatile storage has to be done by writing the "save"- signature (0x65766173) on

- object 0x1010/4

- object 0x1010/1 (only RSX-7900/RFX-6900 series).

These changes will become effective after a communication restart or a power up.

Changing the Node-ID will affect all COB-IDs according to the "predefined connection set".

Example: COB-ID TPDO1 = 0x180 + (Node-ID)

BIT-RATE

Using writing to object 0x2001; non-volatile storage has to be done by writing the "save"- signature (0x65766173) on

- object 0x1010/4

- object 0x1010/1 (only RSX-7900/RFX-6900 series).

These changes will become effective after a communication restart or a power up.

1.7.2 SDO Upload

The SDO upload service is used to read the parameters.

Command 0x40: read command, parameters from encoder
Command 0x4_: 0x42 read command, unspecified size, parameter from encoder
0x43 read command, 4 Byte parameter from encoder
0x47 read command, 3 Byte parameter from encoder
0x4B read command, 2 Byte parameter from encoder
0x4F read command, 1 Byte parameter from encoder

| COB-ID | DLC | Rx/ Tx | Command | Byte0 | Byte1 | Byte2 | Byte3 | Byte4 | Byte5 | Byte6 |
|---------------|-----|-----------|---------|-------|-------|-----------|----------|-------|-------|----------|
| 0x600+Node-ID | 8 | Rx | 0x40 | Index | | Sub-index | 0x00 | 0x00 | 0x00 | 0x00 |
| 0x580+Node-ID | 8 | Tx | 0x4_ | Index | | Sub-index | Data LSB | Data | Data | Data MSB |

1.7.3 SDO Abort

If the SDO download or SDO upload service fails for any reason, the sensor responds with a SDO abort protocol.

| | | |
|-------------|------------|-------------------------|
| Abort Code: | 0x06090011 | subindex does not exist |
| | 0x06090030 | value exceeded |
| | 0x06020000 | object does not exist |
| | 0x06010001 | object is write only |
| | 0x06010002 | object is read only |
| | 0x06060000 | access error |
| | 0x08000020 | data transport error |
| | 0x08000000 | general error |
| | 0x08000022 | wrong state |

| COB-ID | DLC | Rx/ Tx | Command | Byte0 | Byte1 | Byte2 | Byte3 | Byte4 | Byte5 | Byte6 |
|---------------|-----|-----------|---------|-------|-------|-----------|------------|-------|-------|-------|
| 0x580+Node-ID | 8 | Tx | 0x80 | Index | | Sub-index | Abort code | | | |

1.8 Process Data PDO

Process Data Objects (according CiA DS 301) manage the process data exchange, f.e the cyclical transmission of the position value. The process data exchange with the CANopen PDOs is a very slim process without protocol overhead.

1.8.1 PDO Default Setting

2 Transmit PDOs (TPDO) with each max. 8 bytes are provided:

0x1800 TPDO1: default: Event-driven (changeable to synchronous)

0x1801 TPDO2: default: synchronous

1.8.2 PDO Parameter Setting

The contents of the encoder-specific TPDOs can be configured by variable mapping according to customer's requirements. This mapping has to be performed for the encoder as well as for the receiver. The PDO is limited to a maximum size of 8 bytes and 5 mappings per each PDO.

| Mappable objects | | |
|------------------|----------------------|------|
| Index/Subindex | Entry | Byte |
| 0x6020/1 | Position value ch. 1 | 4 |
| 0x6020/2 | Position value ch. 2 | 4 |
| 0x6030/1 | Speed value ch. 1 | 2 |
| 0x6030/2 | Speed value ch. 2 | 2 |
| 0x6300/1 | Cam state ch. 1 | 1 |
| 0x6300/2 | Cam state ch. 2 | 1 |
| 0x6400/1 | Work area ch. 1 | 1 |
| 0x6400/2 | Work area ch. 2 | 1 |
| 0x6503 | Alarms | 2 |
| 0x6505 | Warnings | 2 |

Step 1: For changing of mapping, the sensor must be in properational mode and the MSB of PDO COB-ID has to be set to 1 to deactivate it.

| PDO | Object | COB-ID for active PDO | COB-ID for disabled PDO (MSB set to 1) |
|-----|--------|-----------------------|--|
| 1 | 0x1800 | 0x40000xxx | 0xC0000xxx |
| 2 | 0x1801 | 0x40000xxx | 0xC0000xxx |

Step 2: Clearing entries in mapping table of PDO1 (PDO2) => subindex 0x0 of object 1A00 (1A01) has to be set to 0x00.

Step 3: Mapping of objects into PDO

Example:

A PDO shall be mapped in a way that the "current position" and the "current speed" are transmitted in one PDO.

Mapping #1 "current position":

object 0x1A00/1 size: 32 bits = 4 byte => 0x20 position value = object 0x6020/1

| | | | | destination object | | | size | source object | | | |
|---------------|-----|-------|---------|--------------------|----------------|------------------|-------|------------------|----------------|----------------|--|
| COB-ID | DLC | Rx/Tx | Command | Byte0 (object) | Byte1 (object) | Byte2 (subindex) | Byte3 | Byte4 (subindex) | Byte5 (object) | Byte6 (object) | |
| 0x600+Node-ID | 8 | Rx | 0x23 | 0x00 | 0x1A | 0x01 | 0x20 | 0x01 | 0x20 | 0x60 | |

Mapping #2 "current speed":

object 0x1A00/2 size: 16 bit = 2 byte => 0x10 speed value = object 0x6030/1

| | | | | destination object | | | size | source object | | | |
|---------------|-----|-------|---------|--------------------|----------------|------------------|-------|------------------|----------------|----------------|--|
| COB-ID | DLC | Rx/Tx | Command | Byte0 (object) | Byte1 (object) | Byte2 (subindex) | Byte3 | Byte4 (subindex) | Byte5 (object) | Byte6 (object) | |
| 0x600+Node-ID | 8 | Rx | 0x23 | 0x00 | 0x1A | 0x02 | 0x10 | 0x01 | 0x30 | 0x60 | |

Step 4: Setting entries in mapping table => subindex 0x00 of object 1A00 has to be set to the numbers of mapping entries (e.g. 0x03)

Step 5: For re-activating the PDO, the MSB of PDO COB-ID has to be set to 0.

| PDO | Object | COB-ID for disabled PDO | COB-ID for enabled PDO (MSB cleared) |
|-----|--------|-------------------------|--------------------------------------|
| 1 | 0x1800 | 0xC0000xxx | 0x40000xxx |
| 2 | 0x1801 | 0xC0000xxx | 0x40000xxx |

Note:

TPDO1 value for Event Timer must always be higher than the value for Inhibit Time (except for value 0).

Failed sending of TPDOs can occur if:

- more TPDOs shall be sent than the CANbus may accept due to insufficient CAN bit rate compared to TPDO/Event Timer
- excessive bus load or unfavourable setting of COB-ID in the CANopen network prevents TPDO sending
- Object 0x1800/5- event timer- is set to 0.

1.9 Error Handling

Depending on the type of error occurred, the sensor will react accordingly:

| Error Class | Error | Error Message from Sensor |
|---------------------|--|--|
| Protocol error | SDO protocol error, corrupted data received via SDO | Abort SDO Transfer* |
| | PDO protocol error, corrupted data received via PDO | Not relevant, sensor does support TPDOs only |
| Communication error | CAN bus off CAN error passive CAN overrun CAN buffer overflow | EMCY message** |
| Process error | Position or sensor error | EMCY message**, position value is set to 0x7FF0 (beyond measuring range), speed value is set to 0x0000 |
| | Data error | Abort SDO Transfer* or EMCY message** |
| Change of state | According to Cams and Work Areas | EMCY Message** |

* according to DS-301, see chapter 1.7 SDO Services

** details see chapter 1.9.1 Emergency Messages

1.9.1 Emergency Messages

| COB-ID EMCY | DLC | Rx/ Tx | Byte0 | Byte1 | Byte2 | Byte3 | Byte4 | Byte5 | Byte6 | Byte7 |
|--------------|-----|-----------|----------------|-------|-------|-------|-------|-------|-------|-------|
| 0x80+Node-ID | 8 | Tx | See next table | | | | | | | |

COB-ID EMCY in object 0x1014.
Error-Register in object 0x1001.

0x50xx Device Hardware
0x80xx Monitoring

0x60xx Device Software
0x90xx External Error

| Error-Code Byte 0,1 | Error-Register Byte 2 | Additional Byte | | | Description |
|------------------------|--------------------------|-----------------|----------|--------|--|
| | | Byte 3,4 | Byte 5,6 | Byte 7 | |
| 0x0000 | 0 | 0 | 0 | 0 | <i>Sensor Error resetted, no Error</i> |
| 0x5000 | 1 | 1 | 1 | 0 | <i>Sensor Error</i> <u>Cause:</u> An internal error bit is set. The current process values stay in the object directory; the cam and work area states stay unchanged. If the internal error bit is reset to 0, an EMCY with 0x0000 is sent. |
| 0x6000 | 1 | 1 | 0 | 0 | <i>Insufficient Event Timer Value</i> <u>Cause:</u> CAN bit rate has been set to a low value and an insufficient Event Timer value has been set for TPDO1 accordingly. <u>Reaction:</u> TPDO1 sending will occur partially. |
| 0x8110 | 1 | 1 | 0 | 0 | <i>CAN Controller Overflow , CAN Overrun</i> <u>Cause:</u> data buffers of CAN controller are still holding data and cannot accept new entries. Data is being lost. <u>Reaction:</u> none |
| 0x8110 | 1 | 2 | 0 | 0 | <i>CAN Buffer Overflow</i> <u>Cause:</u> data buffers of CANopen library are still holding data and cannot accept new entries. Data is being lost. <u>Reaction:</u> none |
| 0x8120 | 1 | 0 | 0 | 0 | <i>CAN Error Passive</i> <u>Cause:</u> CAN controller has detected communication errors and is reporting error passive. <u>Reaction:</u> none |
| 0x8140 | 1 | 0 | 0 | 0 | <i>CAN Recovered From Bus-Off</i> <u>Cause:</u> CAN controller registered too many sending errors. CAN communication could be restored afterwards. <u>Reaction:</u> none |
| 0x9080 | 1 | ch. | cam | state | <i>Encoder CAM</i> <u>Cause:</u> the state of cam / channel has changed. State is coded according to 0x6300. <u>Reaction:</u> none |
| 0x9090 | 1 | ch. | 0 | state | <i>Work Areas</i> <u>Cause:</u> the state of Work Area / chan. has changed. State is coded according to 0x6400. <u>Reaction:</u> none |

1.10 Error Objects

1.10.1 Manufacturer-specific Status

The object 0x1002 shows the sensor status bit code and is used for internal process control purposes.
For servicing this information can be requested via SDO (see chapter 1.7 SDO Services).

| Bit | Definition (if bit value = 1) |
|-----|--|
| 16 | sensor receiving process data |
| 15 | TPDO1 Event Timer Value insufficient for set CAN bit rate |
| 6 | CAN Controller Overflow |
| 5 | CAN Buffer Overflow |
| 4 | CAN Error Passive |
| 3 | CAN Bus-Off |
| 2 | CAN Bus-Off Timer started |
| 0-1 | NMT Condition of Sensor %11 stopped %10 operational %01 pro-operational %00 initialisation |

1.10.2 Alarms

Interpretation of object 0x6503:

| Bit | Definition (if bit value = 1) |
|-----|---|
| 12 | No magnet, position reading failed |
| 0 | 2-channel version: difference between positions is out of range |

1.10.3 Warnings

Interpretation of object 0x6505:

| Bit | Definition (if bit value = 1) |
|-----|----------------------------------|
| 12 | Magnet out of operation distance |

1.11 Non-Volatile Storage and Data Restoration

Default values for all data objects are stored in the non-volatile program memory.
Data encryption to the non-volatile memory is only admitted in the pre-operational status.

• Storage via LSS

Data must be stored through the LSS Service Configuration/Store while in LSS Configuration Mode (see chapter 1.6 LSS / Layer Setting Service)

• Storage via SDO Object 0x1010

Data is stored in the non-volatile memory during encryption of object 0x1010 subindex 1/2/3/4 with „save“ signature (0x65766173).

Note: The signature „save“ must not be sent to object 0x1010 subindex 5, otherwise a possible custom configuration is overwritten!

- Only RSX-7900/RFX-6900 series:

Data is stored in the non-volatile memory during encryption of object 0x1010 subindex 1/2/3 with „save“ signature (0x65766173).



CAUTION: In case of custom programmed parameters like node-ID, averaging, bit rate etc. these will be reset to default in case of the corresponding reset command below (default values see chapter 1.3).

• Load via SDO Object 0x1011

Encryption of object 0x1011 subindex 1/2/3/4 with the signature „load“ (0x64616F6C) will upload data from the non-volatile memory.

- Only RSX-7900/RFX-6900 series:

Encryption of object 0x1011 subindex 1/2/3 with the signature „load“ (0x64616F6C) will upload data from the non-volatile memory.



CAUTION: In case of custom programmed parameters like node-ID, averaging, bit rate etc. these will be reset to default in case of the corresponding reset command below (default values see chapter 1.3).

• **Deletion and Restoration to Default via SDO Object 0x1010**

Additionally to the functionality defined in CiA standard DS-301, CANopen library offers the possibility to delete data in the non-volatile memory.

Delete process is initiated by sending the signature "kill" (0x6C6C696B) to object 0x1010 subindex 1/2/3/4.

By sending the signature "kill" to object 0x1010 subindex 1/2/3/4, default settings are being restored (see chapter 1.7 *SDO Services*). In case of custom factory programmed parameters like node-ID, averaging, bit rate etc., these will be retained.

- Only RSX-7900/RFX-6900 series:

Delete process is initiated by sending the signature "kill" (0x6C6C696B) to object 0x1010 subindex 1/2/3.



CAUTION: In case of custom programmed parameters like node-ID, averaging, bit rate etc. these will be reset to default in case of the corresponding reset command below (default values see chapter 1.3).

• **Manufacturing Mode Object 0x1010**

- Not RSX-7900/RFX-6900 series:



If the sensor is out of function and the signature "boot" 0x746F6F62 in object 0x1000 (device type) is active, the sensor is in manufacturing mode. This mode can be left by power off-on or via the operational command.

| Object 0x1010 Object 0x1011 | Subindex /1 All | Subindex /2 Communication | Subindex /3 Application | Subindex /4 User data <small>Only RSX/RFX: Manufacturer</small> |
|----------------------------------|--------------------|------------------------------|----------------------------|---|
| COB-ID Sync | X | X | | |
| Guard Time | X | X | | |
| Life Time Factor | X | X | | |
| Heartbeat Timer | X | X | | |
| TPDO COB-ID | D | X | | |
| TPDO Trans Typ | X | X | | |
| TPDO Inhibit Time | X | X | | |
| TPDO Event Timer | X | X | | |
| TPDO Mapping | X | X | | |
| NMT Startup | X | X | | |
| Node-ID | Only RSX/RFX: X | | | Not RSX/RFX: X |
| Bit Rate | Only RSX/RFX: X | | | Not RSX/RFX: X |
| Ordering | | | | Only RSX/RFX: X |
| Custom | | | | Only RSX/RFX: X |
| Operating Parameters | X | | X | |
| Measurement units per Revolution | X | | X | |
| Total Measurement Range | X | | X | |
| Preset Value | X | | X | |
| CAM Enable | X | | X | |
| CAM Polarity | X | | X | |
| CAM Low Limit | X | | X | |
| CAM High Limit | X | | X | |
| CAM Hysteresis | Not RSX/RFX: X | | X | |
| Work Area Low Limit | Not RSX/RFX: X | | X | |
| Work Area High Limit | Not RSX/RFX: X | | X | |

X: data saved or restored

D: data set to default value

1.12 Abbreviations

| | |
|--------|--|
| CAN | Controller Area Network |
| ch | channel |
| COB-ID | Communication Object Identifier |
| const | constant parameter, only readable |
| DLC | Data Length Code |
| DS | Draft Standard |
| EMCY | Emergency Service |
| NMT | Network-Management |
| PDO | Process Data Object |
| Pos | Position (value) |
| ro | read only, parameter can change |
| rw | read/write |
| Rx | Novotechnik sensor is consumer of the CAN data frame |
| SDO | Service Data Object |
| SYNC | Synchronisation message |
| TPDO | Transmit Process Data Object |
| Tx | Novotechnik sensor is producer of the CAN data frame |

1.13 Document Changes

| Revision | Changes | Date | Who |
|----------|--|----------------------|-------|
| V00 | First edition | 30.06.14 | VM/mm |
| V01 | Object 6200 (cycle timer) deleted | 13.08.14 | VM/mm |
| V02 | Defined value added for error case "data error" | 18.05.14 | VM/mm |
| V03 | Object 0x2002 chip temperature deleted | 18.06.15 | VM/mm |
| V04 | Typo corrected (page 10/11/16), 1.2.1 rev.no. not on product label, 1.6.4.1 work area supervision deleted, 1.1. description eds-file corrected (1-/2-channel) | 28.01.16 | VM/mm |
| V05 | 1. Chapters starting with #1 (instead of 5). 1.2.1 Product series RSA-3200 and RFE-3200 added, 1.2.2 customized Node-ID added. 1.5 Switch Mode Global: correction of byte 0 and byte 1, 1.3 Object Index 1A00/2 and 1A01/2: ¹⁾ and ²⁾ exchanged | 06.12.16 | VM/mm |
| V06 | Product series RSX-7900 and RFX-6900 added | 28.08.17 | VM/mm |
| V07 | 1.2.5 description of transmission modes modified, 1.4.2, 1.4.3 default value 0x3FFF corrected to 0x4000 (14 bits), 1.3.1 Object 1801/1 "+ Node ID" added, 1.3.3 CAN bit rate: default value corrected (0xFA instead of 0x03) and note about "reset all" added ("Caution:..."), 1.7.1 description modified: event-driven instead of asynchronous, 1.10 note about "reset all" added | 22.05.18 | VM/mm |
| V08 | obsolete | - | - |
| V09 | 1.2.5 and 1.3.1 object 1801x2: event driven transmission deleted for TPDO2. 1.3.1 objects: TPDO1 and TPDO2: name modified. 1.3.1 object 1800/2 and 1801/2 comment: synchronous 1...240 instead 1...239, TPDO off: 0 added | 01.04.20 | VM/mm |
| V10 | Modifications for new firmware release (NOT valid for RSX-7900/RFX-6900 series!): 1.3.1 Object 1010/4 user data parameters instead of manufacturer defined parameters, object 1010/5 manufacturer defined parameters added. Object 1011/4 user data parameters instead of manufacturer defined parameters 1.3.3 Object 2001 CAN bit rate: note about "reset all" dedicated to RSX/RFX series only , 1.6.1 Node-ID: save-signature on object 0x1010/4 instead of 1010/1, Bit-Rate: save-signature on object 0x1010/4 instead of 1010/1. 1.10 Storage via SDO: object 0x1010: subindex 1/2/3/4 added. Headline added "Load via SDO", object 0x1011: subindex 1/2/3/4 added. Headline changed "Deletion and Restoration to Default via SDO", Kill object 0x1010: subindex 1/2/3/4 added, custom factory programmed settings are being restrained (RSX/RFX: reset to default), note added regarding subindex 5. Subindex /4: User data instead of Manufacturer. Table: Note-ID and Bit Rate => saved/stored with subindex /4 instead of subindex /1. CAM Hysteresis, Work Area Low/High Limit => saved/stored with subindex /1, Ordering/Custom dedicated to RSX/RFX. General modifications: 1.2.2 Node-ID object 0x2000 instead of 0x2001. 1.3.1 object 2003 not writable for the customer added. 1.3.2 Object 650C offset value deleted. 1.6.2 textual adaptations. | 12.05.20 | VM/mm |
| V11 | 1.3.1 object 1010/5: added. 1.10. signature kill 6C6C696B instead of 6B696C6C, comment regarding manufacturing mode added | 07.12.20 | VM/mm |
| V12 | 1.2 Support added, all further chapter numbers changed 1.8.3 Textual modifications | 07.09.21 17.11.22 | VM/mm |
| V13 | 1.7.1 Corrected example for setting the node ID | 17.02.23 | VM/mm |

| Revision | Changes | Date | Who |
|----------|---|----------|-------|
| V14 | 1.3.3 Resolution speed added | 21.04.23 | VM/mm |
| V15 | 1.11 COB-ID Sync: x=valid for Subindex/1 and /2 | 08.03.24 | VM/mm |
| V16 | Document history V1 ... V16 completed | 12.07.24 | VM/mm |